


Y88

ELECTRIC DIRT BIKE

OWNER 'S MANUAL

Read and understand this entire manual before using this products !
for assistance contact customer service .
DO NOT RETURN .



Dirt bike is to be used in OFF-ROAD AREAS ONLY, check your local law before riding, please read manual for information or assembly and product features.

Y88


ELECTRIC DIRT BIKE

WELCOME

please refer to actual product.

BOX CONTENTS

- Electric dirt bike
- owner's manual
- Accessory- charger
- Accessory - front wheel
- Accessory - front fender
- Accessory-installation tool
- Accessory-head 1 lg ht
- Accessory-cover chain




Y88

ELECTRIC DIRT BIKE

THE Y88 ELECTRIC DIRT BIKE IS FOR 14+ USER AND SHOULD ONLY BE RIDDEN CAREFULLY AND RESPONSIBLY BY APPROPRIATELY MATURE AND RESPONSIBLE RIDERS EXERCISING CAUTION AND RESPECTING APPLICABLE LAWS.

This product is not a toy for your riders' This product is manufactured to be used OFF-ROAD ONLY and is not designed or intended to be street legal. X1000 emphasizes the importance of riders to understand the risks associated with riding and electric dirt bike. Bluntly put, you could get hurt and your actions could cause injury to others. You must be cautious, alert and take reasonable precautions to minimize such risks or falls, impacts or other dangerous situations. The user must be, and is, responsible for determining whether local laws permit use of the X1000 in varying circumstances (there is no "uniform Federal law" in existence to establish universal riding conditions), the rider must be, and is, responsible for acting maturely, carefully and with respect for potentially adverse riding conditions including darkness or impaired visibility, fog, rain, snow, hail, ice or electrical storms, which increase the dangers inherent in operation and electric dirt bike. The rider must be, and is, responsible for adjusting riding behavior and braking distance to suit the weather and riding conditions, and also to recognize that riding in low visibility conditions decreases your ability to see and be seen.

It is absolutely recommended that any rider wear a proper helmet to minimize potential head injuries, use of the X1000 electric dirt bike is recommended for mature riders - using age 14+ (the generally recognized age of "legal consent") as guide. Riders of the X1000 electric dirt bike must respect and adhere to all locally applicable laws and rules applicable to the use of such products, be legal and be safe!



Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Riding presents potential risks and caution is required. When riding this electric dirt bike there are inherent hazards associated with its use (for example: falling off or riding it into A hazardous situation). Like any riding product X1000 is intended to move, therefore, it is possible to lose control or otherwise get into dangerous situations, Riders must recognize That if such things occur, a rider can be seriously injured or die, even when using safety Equipment and other precautions. RIDATYOUR OWN RISKAND USE COMMON SENSE.

Always check and obey any local laws or regulations. These may affect the locations where X1000 electric dirt bike may be used. This bike is for off, road use only, riding on public streets may result in legal action or risk of traffic-related injuries.

X1000 electric dirt bike is for nature riders, it is only to be used I off, road conditions, or as legally permitted, personal responsibility and compliance local laws is imperative and is the rider's responsibility. Only use where allowed and with caution.

NOT FOR RIDERS UNDER AGE 14 OR HEAVIER THAN 265 LB (120KG). DO NOT EXCEED THE WEIGHT LIMIT OF 265 LB (120KG)-including backpacks and other terms that might be carried. Exceeding the weight limit could injure the rider and damage the X1000). rider weight alone also does not necessarily mean a person's size is appropriate to fit or maintain control or the X1000, keep this product away from small children and remember that this product is not a toy and is intended for use only by persons who are, at a minimum, completely comfortable and competent while operating the product.

NECESSARY TO BE RIDDEN BY MATURE RIDERS: Because products, like the X1000,can and do present potential hazards plainly associated with their use, it is well recognizedUSE BEST JUDGMENT WHEN DETERMINING WHETHER OR NOT TO RIDE, not everyone is suited to ride this product, physical and mental abilities should be considered before rider.

Y88

ELECTRIC DIRT BIKE

⚠ SAFETY WARNING

It is for ADULT USE ONLY, children under the age of 14 not be permitted to use this product. This recommendation is based not just on age or weight or height, it reflects consideration of expected maturity and skills as well as physical size. The recommended rider age of 14 years or older is only an estimate and can be affected by the rider's size, weight or skills - not every rider 14 years old or older will be suited to the product. Certainly any rider unable to fit comfortably on the X1000 electric dirt bike should not attempt to ride it.

⚠ SAFETYINSTRUCTIONS

Keep this product away from small children and remember that: it is intended for Adult use Only by persons who are, at a minimum, completely comfortable and competent while operating the X1000 electric dirt bike.Persons with any mental or physical conditions that may make them susceptible to injury, impair their physical dexterity or mental capabilities to recognize, understand,and follow safety instructions and to be able to understand the hazards inherent in the use of any ride-on product should not use or be permitted to use products Riding at night or when visibility is limited increases inappropriately for their abilities. Persons with heart conditions, head,back or neck ailments (or prior surgeries tothese areas of the body), or pregnant women, should be cautioned not to operate the X1000 electric dirt bike.

DO NOT EXCEED THE WEIGHT LIMIT OF 265LB(120KG)Rider weight does not necessarily mean a person's size is appropriate to fit or maintain control; of the X1000.

BEFORE use, check to confirm that covers and guards are in place and in serviceable condition, Check that the brakes and display are functioning properly, that the tires are inflated properly and have sufficient tread remaining. The product should be maintained and repaired in accordance with the manufacturer's specifications using

Y88

ELECTRIC DIRT BIKE

only the manufacturer's authorized replacement parts, and should not be modified from the manufacturer original design and configuration.

ACCEPTABLE RIDING PRACTICESAND CONDITIONS

Do not activate the throttle unless you are on the X1000 and in a safe outdoor environment suitable for riding. Once the throttle is activated the X1000 will move forward.

The normal powered top speed of this product will be approximately 50mph (31.07km/h),which can be affected by conditions, such as rider weight, inclines and batterycharge level.

Avoid excessive speeds that can be associated with downhill ridesMaintain a hold on the handlebars at all times. Do not touch the brake rotors or motoron your X1000 when in use or immediately after riding, as these parts canbecome very hot.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

your path, and respect the rights and property of others. The X1000 is intended for use on off, road surfaces, such as loose debris, sand, leaves, rocks or gravel. Wet, slick, bumpy, uneven or rough surfaces may impair traction.

and contribute to possible accidents. Do not ride your product on ice, puddles or water. Watch out for potential obstacles that could catch your wheel or force you to swerve suddenly or lose control. Avoid sharp bumps, asphaltroads and sudden surface changes. Use caution when attempting stunts or tricks on the X1000, the X1000 is not made to withstand abuse from misuse, such as aggressive jumping, curb grinding or any other type of stunts. Racing, stunt riding, or other maneuvers also enhance risk of loss of control, or may cause controlled rider action or reactions.

Riding at night or when visibility is limited increases risks of accident or injury. Should the X1000 be ridden in such conditions, use of light and additional measures to increase rider visibility and X1000 conspicuous are advised.

Riding at night or when visibility is limited increases risks of accident or injury. Should the X1000 be ridden in such conditions, use of light and additional measures to increase rider visibility and X1000 conspicuous are advised.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

⚠ WARNING

Single Rider. This product is designed for one person only. Do not carry passengers or other items. Never allow more than one person at a time to ride the product. Never use near steps or swimming pools.

The X1000 can operate more quietly than other motorized products may operate. Use care when in the vicinity of pedestrians or others who may have difficulty hearing your approach.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is engaged.

Do not touch electric motor or brake rotors when in use or immediately after riding.

Never ride your product while under the influence of drugs or alcohol.

PROPER RIDING ATTIRE

Always wear proper protective equipment, such as an approved safety helmet(with chin strap securely buckled), elbow pads, and knee pads. A helmet may be legally required by local law or regulation in your area, A long-sleeved shirt, and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and motor. Never ride barefooted or in sandals.

⚠ WARNING

please make sure to sue the supplied manufacturer's lithium-ion battery charger, Turn off the circuit switch is installing or removing, the battery from the bike, it is risky to connect the power cable while the circuit switch is on, it might cause spark and damaged the plug, it may even damage the battery. The charger will be automatically turned off when the battery is fully charged, however, please avoid leaving the charger connected to the power supply for too long.

⚠ WARNING

When using this product, basic precaution should always be followed, including the following:

- Read all the instructions before using product.
- Do not put fingers or hands into the product.
- Do not use this product if the flexible power cord or output cable is frayed, has brake insulation or an other signs of damage.

Y88

ELECTRIC DIRT BIKE

